C122-E200-01EN

FUJITSU Server
PRIMEQUEST 2000/1000 Series
Notes on ServerView Suite

February 24, 2014

FUJITSU LIMITED

FUJITSU

Contents

I. Preface 3

II. Notes on ServerView Suite V11.14.02 3

1. Notes on ServerView Operations Manager (SVOM) 3

2. Notes on ServerView Agent 5

3. Notes on ServerView RAID 9

4. Notes on ServerView Mission Critical Option (SVmco) 12

5. Notes on ServerView Mission Critical Option for VM (SVmcovm) 17

6. Notes on ServerView ESXi CIM Provider 21

7. Notes on ServerView Installation Manager (SVIM) 21

8. Notes on ServerView Update Manager (SVUM) 27

9. Notes on ServerView Update Manager Express (SVUME) 27

I. Preface

This manual provides notes on ServerView Suite V11.14.02 or later as related to the PRIMEQUEST 2000/1000 series.

II. Notes on ServerView Suite V11.14.02

1. Notes on ServerView Operations Manager (SVOM)

(1) [PRIMEQUEST 2000/1000 Series]

Note the following point about adding a server in the PRIMEQUEST 1000 series to the server list.

When adding a server in the PRIMEQUEST 1000 series to the server list, specify the MMB (ManageMent Board) as the object to be added. If you specify a partition directly, the following message is output, and the object cannot be added.

It is not allowed to add the virtual PRIMEQEUST

(2) [PRIMEQUEST 2000/1000 Series]

In a test of a connection on the PRIMEQUEST MMB, "test trap" in the [Connection Test] window always fails.

Use the test trap function of the MMB to test the trap connection. For details on the test trap function of the MMB, see the following manual:

PRIMEQUEST 1000 Series Tool Reference
1.5.6 [SNMP Configuration] menu
[SNMP Trap] window

(3) [PRIMEQUEST 2000/1000 Series]

In rare cases, a "fatal error" may occur during a new installation or update installation.

In such cases, perform the new installation or update installation again.

(4) [PRIMEQUEST 2000/1000 Series]

As soon as the event detected by the driver monitoring function is resolved, clear the status.

If the status is not cleared, the event of the hardware whose status is not Normal is suppressed, and there is no notification.

Clearing the status:

(1) Open the driver monitoring window from the SVOM window.

(2) Select the component to clear its status, and click the [Approve] button.

(3) Click the [Update] button at the top of the window.

(5) [PRIMEQUEST 2000/1000 Series]

In case of manage the power of Partition, Do not use the power management function on the SVOM .
Use the power Management function on the MMB.

(6) [PRIMEQUEST 2000/1000 Series]

Use SVOM V6.10.05 or later for monitoring VMware vSphere 5. As soon as the event detected by the driver monitoring function is resolved, clear the status.
If the status is not cleared, the event of the hardware whose status is not Normal is suppressed, and there is no notification.

Clearing the status:

(1) Open the driver monitoring window from the SVOM window.
(2) Select the component to clear its status, and click the [Approve] button.
(3) Click the [Update] button at the top of the window.

2. Notes on ServerView Agent

(1) [PRIMEQUEST 2000/1000 Series]

The event information displayed by driver monitoring is cleared after an operating system or SVAgent restart.

(2) [PRIMEQUEST 1000 Series]

In operation with Red Hat Enterprise Linux 6, if a hard disk connected to an SAS card fails and becomes unresponsive, the Fault-LED may not go on.In such cases, use the following method to find the fault location.

1) If a hard disk connected to an SAS card fails and you receive notification of the failure, obtain PrimeCollect.
2) Check the device name in syslog.

```
Aug 26 22:40:11 RHEL6-SP1-GA-x64 kernel: scsi 1:0:2:0: rejecting I/O to offline device
Aug 26 22:40:11 PSA-RHEL6-SP1-GA-x64 kernel: scsi 1:0:2:0: [sdc] Unhandled error code
Aug 26 22:40:11 PSA-RHEL6-SP1-GA-x64 kernel: scsi 1:0:2:0: [sdc] Result: hostbyte=DID_NO_CONNECT
driverbyte=DRIVER_OK
Aug 26 22:40:11 PSA-RHEL6-SP1-GA-x64 kernel: scsi 1:0:2:0: [sdc] CDB: Read(10): 28 00 08 8f c1 00 00
00 08 00
                                        :
                                        :
Aug 26 22:40:18 RHEL6-SP1-GA-x64 Serverview: [2151][MINOR] Driver Monitoring warning event at
server RHEL6-SP1-GA-x64: RH61_offline_101 (PID=3) 14123, Unknown scsi:sd_1:0:2:0 Device or
Software error (rejecting I/O to offline device) vendor=<VENDOR> model= serial-no=
```

Find the logged event (14123) detected by ServerView. Then, find the item logged before it ([rejecting I/O to offline device]).The numbers shown immediately before the message are Host:Channel:Id:Lun (1:0:2:0 in the above example).The device name (sdc in the above example) can be found from the log item that has the same Host:Channel:Id:Lun.

3) You can find the mounting location of the faulty disk from the obtained PrimeCollect.
Open PrimeCollect, and open the var\log\PrimeCollect\tmp\PCSysScan.xml file in Word.

```
1
MBD2300RC
FUJITSU
D007PA902HT0
SASU#2-HDD#0
sda

1
MBD2300RC
FUJITSU
D007PA902HRR
SASU#2-HDD#2
sdb

1
MBD2073RC
FUJITSU
BSF2P780004J
SASU#2-HDD#3
sdc
```

From the device name (sdc in the above figure), confirm the mounting location.(SASU#2-HDD#3 in the above example)

(3) [PRIMEQUEST 1000 Series]
Fujitsu does not support rsyslog in Red Hat Enterprise Linux 5.If rsyslog is installed, ServerView Agent cannot detect and report errors in I/O (PCI-Express card, hard disk, etc.).

(4) [PRIMEQUEST 1000 Series]
You have a possibility the following message logged even if target system has no error when monitoring VMware ESX 4.x by SVOM,

"Memory module 'DIMM-0D2(Memory Board 2)' in cabinet 0 of server pqesx01 is failing. Too many errors have occurred."

It caused by slow process of VMware. When ServerView Agents try to get memory status, it takes a lot of times. Therefore the process become timeout and logged error.
To avoid this timeout, try to the following workaround.

<Workaround>

1. Calculate the time during booting by using boot completed time of EM_IPMI2 module from /var/log/srvmagt/log.eecd
   E.g.
   The following message will be logged on the top of log.eecd file.
   Jan 12 10:58:24 VMware40U1 eecd[F7F026C0]: ServerView Agent eecd Version="4.92-60" Milestone="N15" Built="2010/07/20-18:15" Start="Jan 12 10:58:23" Wrap="0"
   You can know the boot completed time of EM_IPMI2 module by finding the following message in the log.eecd file.
   Jan 12 11:01:44 VMware40U1 eecd[F7F026C0]: Module EM_IPMI2 started
   In this case, system start at Jan 12 10:58:24 and boot completed Jan 12 11:01:44.
   You can find the booting takes 3 min. 20 sec.(200 sec.)

2. Execute the following procedure.
   A) Become “root” user
   B) Stop ServerView Agents
      # /usr/sbin/srvmagt stop
   C) Move to the directory for setting file.
      # cd /etc/srvmagt
   D) Change the [EM_IPMI2] value in the Module.ini(only for V5.30 or previous version)
      [EM_IPMI2]
      StartTimeout=300

      Note) In this case, Change the default valu(180 sec.) to 300.
            This value are calculated as the below.
            The vale calculated in step 1(200) x 1.5 = 300
   E) Change the [General] value in the Module.ini
      [General]
      StartTimeout=420

Note) In this case, you should add same value that is difference between default value and current [EM_IPMI] value.

F) Change the boot script of ServerView Agents : /etc/init.d/srvmagt
Line 275: count=420

Note) you should use same value as [General] in step E for this property.

G) Start ServerView Agents
/usr/sbin/srvmagt start

3. Confirm the error message still logged or not.

In case of the error logged, you can find the flowing message in /var/log/srvmagt/log.eecd_a file.(not log.eecd file)

* TIMEOUT!! Module EM_IPMI2 did not start within

Confirm workaround avoid the error specified the above. New log.eecd_a file will be created every ServerView Agents booting.
If still the error logged, Change the timeout value more long and try workaround specified the above.

Note : the time depend on the configuration of the system. If configuration becomes bigger, you should set more long time.

(5) [PRIMEQUEST 1000 Series]
Use Linux version of Agents V6.10.06 or higher. If you have SSD drive on the PCI slot.

(6) [PRIMEQUEST 1000 Series]
Use Windows version of Agents V6.10.05 or higher, If you will use Windows Server 2012

(7) [PRIMEQUEST 1000 Series]
Use Linux version of Agents V6.10.06 or higher If you will use Oracle VM.

(8) [PRIMEQUEST 2000/1000 Series]
Check the I/O on the SVOM after OS booting, because it has possibility to fail the log monitoring during OS booting phase.

(9) [PRIMEQUEST 2000 Series]
In case of environment which installed Windows Server 2008 R2 without ServerView Installation Manager on PRIMEQUEST 2000 Series, You should adopt the following Windows Hotfix before install ServerView Agents
http://support.microsoft.com/kb/2674913/en-us

3. Notes on ServerView RAID

(1) [PRIMEQUEST 1000 Series]

If the diskctrl command is used to execute a "disk rotation stop instruction," ServerView RAID may output the following message. This message is output with the "disk rotation stop instruction" and does not indicate any operational problem.

Event ID: 10451
Message: State change on disk ([..]) from available to failed

<Example of output>
ServerView RAID: [10451][Error] Adapter Linux Multiple Devices (0): State change on disk (sdb 8:16) from available to failed

(2) [PRIMEQUEST 2000/1000 Series]

In a Windows environment, if the following event (ID 51) occurs, a RAID card may have failed. Use the following procedure to check whether the RAID card failed and to replace a failed card.

1) Confirm that the following event was recorded in the event log.
   Event ID: 51
   Type:Warning
   Source:Disk

   Description:An error during paging was detected on the device \Device\Harddiskx\DRy.
   >> If the event was recorded, go to step 2).

2) Confirm that the ServerView RAID window displays the device where the error occurred as described in the above step 1).
   >> If the device is not displayed even though it is mounted, go to step 3).

3) Confirm that the ServerView RAID window displays the RAID controller card on the device described the above 2).
   >> If the RAID controller card is not displayed even though it is mounted, replace it.
   (SAS array disk unit or external RAID card)

In the above case, follow the troubleshooting information provided by Microsoft.

(3) [PRIMEQUEST 1000 Series]

In case of monitoring RAID on PRIMEQUEST 1000 series with VMware vSphere 5, install ServerView RAID to guest OS which ServerView Mission Critical Option for VM installed.

(4) [PRIMEQUEST 1000 Series]

Use correspond version of software combination for detect and inform error of ServerView RAID.

If you use the following software without the combination that specified the following table, you will have some problem about RAID error handling. E.g. No error event informed or error event information become garbled when error detected on the RAID.

Related Software : PRIMEQUEST Server Agent (PSA)/ ServerView Mission Critical Option (SVmco)/ ServerView Mission Critical Option for VM (SVmcovm)/ServerView Agents

Refer the following table and find correspond combination of software.

Model Name	Software name	OS	ServerView RAID version	
			V5.7.3	V5.7.8 or later *2
PRIMEQUEST 1400S/1400E/1400L/1800E/1800L	PRIMEQUEST Server Agent	Windows2003/ Windows2008	x64 OS : 2.11.1 or later x86 OS : 2.11.0 or later	2.16.x or later (planned)
		RHEL5	2.12.0 or later	2.16.0 or later
		RHEL6	2.11.1 or later	2.17.0 or later
		VMware ESX4.0/4.1	2.12.0 or later	2.16.0 or later
PRIMEQUEST 1400S2 Lite/1400S2/ 1400E2/1400L2/1800E2/1800L2	ServerView Agents	Windows2008/ Windows2012	V6.11.03 or later	V6.21.07 or later
		RHEL5/ RHEL6	V5.50.20 or later	V6.21-20 or later
		VMware ESX4.0/4.1	V6.00.10 or later	V6.21-20 or later
	ServerView Mission Critical Option	RHEL5/ VMware ESX4.1	1.0.5 or later	
		RHEL6	1.0.5 or later	
		Windows2008	x64 OS : 1.8.1 or later x86 OS : 1.0.3 or later	

		Windows2012	x64 OS : 1.8.1 or later x86 OS : 1.1.0 or later	
	ServerView Mission Critical Option for VM *1	RHEL5	1.1.2 or later	1.4.0 or later
		RHEL6	1.1.2 or later	1.4.0 or later
		Windows2008	x64 OS : 1.3.1 or later x86 OS : 1.1.1 or later	1.4.x or later (planned)
		Windows2012	x64 OS : 1.3.1 or later x86 OS : 1.2.0 or later	1.4.x or later (planned)

*1 About “ServerView Mission Critical Operation for VM”, “OS” field means OS which installed to virtual system on VMware ESXi 5

*2 The difference of ServerView RAID Manager v5.7.3 and v5.7.8 are the following.

V5.7.3 can’t inform some of event(10987,10988) of ServerView RAID Manager

You can download these software from the following site.

http://support.ts.fujitsu.com/Index.asp

(5) [PRIMEQUEST 1000 Series]

If you find Error event(ID: 18500-18999/28500-28999) from ServerView RAID manager, Execute appropriate action for the event and check ServerView RAID manager GUI another error event available or not.

You found another error event you should execute action for it.

4. Notes on ServerView Mission Critical Option (SVmco)

(1) [PRIMEQUEST 1000 Series]

For monitoring in the PRIMEQUEST 1800E2, install SVmco.

For monitoring in the PRIMEQUEST 1800E, do not install SVmco.

(For the PRIMEQUEST 1800E, PSA monitors and reports errors.)

(2) [PRIMEQUEST 1000 Series]

If SVmco needs to be restarted for the post-SVmco-installation settings in VMware (2.3.3 in the *ServerView Mission Critical Option Version 1.0 User Manual*), execute the following procedure in the terminal window:

```
/sbin/service y30SVmco stop
/sbin/service y10SVmco start
/sbin/service y30SVmco start
```

(3) [PRIMEQUEST 1000 Series]

For the PRIMEQUEST 1800E2 with Windows as the operating system, install ServerView RAID.

Unless ServerView RAID is operating, hardware configuration information about the disk is not sent correctly to the REMCS center..

(4) [PRIMEQUEST 1000 Series]

When you use Oracle VM, please install SVmco V1.2.0 or later in the Host OS.

(5) [PRIMEQUEST 1000 Series]

When you use PCIe SSD card, please install the following SVmco.

- For Linux: SVmco V1.4.1 or later
- For Windows: SVmco V1.2.1 or later

(6) [PRIMEQUEST 1000 Series]

When you use Windows Server 2012, please install SVmco V1.1.0.2 or later.

and, SIRMS V4.5.0.0 or later

Note:

For the PSHED Plugin driver of less than the V1.8.0 edition, the Windows hardware recognition for Windows Server 2012 is uncorrespondence.

The version for the Windows hardware recognition for Windows Server 2012 must use since the 1.8.0th edition.

Please use the SVmco V1.8.0 or later for the Windows Server 2012.

However, If you use the less than SVmco V1.8.0, does not indicate any functionally problem.

(7) [PRIMEQUEST 1000 Series]

Please install the SVmco V1.2.0.0 or later of RHEL5 for the Oracle VM.

(8) [PRIMEQUEST 1000 Series]

"Firmware Version" is not displayed on the Slot of the correspondence of the MMB Web-UI when you're operating Fiber Channel over Ethernet by composing "iSCSI" or "NIC".



Please use One Command Manager of Emulex when you confirm "Firmware Version".

confirmation method of “Firmware Version

The following are selected from the environment of the target.

1.“Start menu” -> "All programs. " -> "Emulex" -> "OCManager"

2.Confirm the “Firmware Version” of the target PCI card in the One Command Manager window.



(9) [PRIMEQUEST 2000/1000 Series]

If you use SVmco v1.4 or later and disable IPv6, you need to remove the setting of the snmptrapd file.

When the setting is not deleted, Trap cannot be received.

In case of the PRIMECLUSTER remove, there are a problem that Trap from another node cannot be received.

Please delete the setting according to the following procedures.

1.Open the /etc/snmp/snmptrapd.conf. and delete the "**udp6:162**".

Before:

```
snmpTrapdAddr udp:162,udp6:162
```

After

```
snmpTrapdAddr udp:162
```

2.Restart snmptrad service. and confirm to start normally

```
#/etc/init.d/snmptrad restart
Stopping snmptrapd:                                        [ OK ]
Starting snmptrapd:                                        [ OK ]
#
```

(10) [PRIMEQUEST 1000 Series]

When you use Windows Server 2012 R2, please install SVmco V1.8.1.0 or later..

Note:

For the PSHED Plugin driver of less than the 1.8.1.0 th edition, the Windows hardware recognition for Windows Server 2012 R2 is uncorrespondence.

Therefore, there is functionally no problem though pop up is output when you install.

5. Notes on ServerView Mission Critical Option for VM (SVmcovm)

(1) [PRIMEQUEST 1000 Series]

Select a virtual machine on the VMware ESXi 5 server to install SVmcovm in a virtual machine.

Virtual Machine is necessary in each partition that runs ESXi.

Refer to “PRIMEQUEST 1000 Series ServerView Mission Critical Option User Manual” for details.

(2) [PRIMEQUEST 1000 Series]

When the environment is configured of VMware vSphere 5, hard configuration information on PCI card/disk is not reported to the REMCS center.

(3) [PRIMEQUEST 1000 Series]

When the environment is configured of VMware vSphere 5, "PCI-Express Card Information" and "Firmware Version" in the table of "PCI-Express Slots" of the MMB screen is not displayed. (IOB or PCI_Box of the menu of the MMB screen).

(4) [PRIMEQUEST 1000 Series]

The following table lists the packages required for SVmcovm operation.

Please confirm necessary package has been installed in the partition before installing SVmcovm.

Remarks:

To install to 64-bit RHEL5 or 6, you need to install “32-bit openssl” package.

Also, you only need to instsall “32-bit glibc” package when you install svmcovm to 64-bit RHEL6.

When these packages are not installed, SVmcovm cannot be normally started.

● Packages (RHEL5)

X86	**X64**
gdb-x.x-x.x.i386	gdb-x.x-x.x.x86_64
tcl-x.x.x-x.i386	tcl-x.x.x-x.x86_64
	openssl-x.x.x-x.x.i686
expect-x.x.x-x.x.i386	expect-x.x.x-x.x.x86_64
openssh-clients-x.x-x.x.i386	openssh-clients-x.x-x.x.x86_64

● Packages (RHEL6)

X86	X64
gdb-x.x-x.x.i686	gdb-x.x-x.x.x86_64
	glibc-x.x-x.x.i686
tcl-x.x.x-x.i686	tcl-x.x.x-x.x86_64
	openssl-x.x.x-x.x.i686
openssh-clients-x.x-x.x.i686	openssh-clients-x.x-x.x.x86_64
expect-x.x.x-x.x.i686	expect-x.x.x-x.x.x86_64

(5) [PRIMEQUEST 1000 Series]

The standard of the amount of the resource of SVmcovm is the following.

Hard Configuration: 1partition and 1SB (2CPU).

● Linux

	At normal	At failure detection
CPU	About 0%	About 1.7%
MEM	About 21MB	About the same (left).
HDD	About 32MB	About the same (left).

● Windows

	At normal	At failure detection
CPU	About 0.4%	About 0.5%
MEM	About 13MB	About the same (left).
HDD	About 13MB	About the same (left).

(6) [PRIMEQUEST 1000 Series]

About the report time at failure detection.

Time in the report message to syslog, REMCS, and Mail is different according to the environment in which SVmcovm is installed.

● RHEL6 :

1)Confirm the time of the following logs output to syslog.

```
SVmco: I 00069 SVPM startup succeeded (/etc/fujitsu/SVmco/global/pmsvmco.conf)
```

2)Compare the time of the red line of the following example and the time examined according to procedure 1.

- After the time that SVmcovm started (procedure 1):
  The report time is local time of a virtual machine in which SVmcovm is installed.

- Before the time that SVmcovm started (procedure 1):
  The report time is reported of with UTC (Coordinated Universal Time).

● RHEL5:

All the report time is local time of a virtual machine in which SVmcovm is installed.

The target time is a red line of the following example.

Refer to “8 Messages” of “PRIMEQUEST 1000 Series ServerView Mission Critical Option User Manual” for details.

■ Syslog

```
Dec 14 19:19:42 RHEL55onVM SVmcovm: E 18565 0:14:0.0 SV RAID:[10.24.76.104] LSI MegaRAID SAS 9280-8e (4)
Device error (State change on disk from operational to offline)
```

■REMCS

SVmcovm P#1 2011-12-15 21:18:50 E 18565 0:14:0.0 SV RAID:[10.24.76.104] LSI MegaRAID SAS 9280-8e (4) Device error (State change on disk from operational to offline)
Dec 15 21:18:50 RHEL55onVM ServerView RAID: [10505][Warning] Adapter [10.24.76.104] LSI MegaRAID SAS 9280-8e (4): State change on disk (1:8) from operational to offline vendor=INTEL model=SSDSA2SH064G1GC serial-no=CVEM008 101VW064KGN

■Mail

SVmcovm P#1 2011-12-28 14:22:50 E 18516 0:14:0.0 SV RAID:[10.24.76.104] LSI MegaRAID SAS 9280-8e (3) Adapter error (BBU temperature problem detected) vendor-id=1000 device-id=0079 revision=
Dec 28 14:22:50 rhel5 ServerView RAID: [10152][Error] Adapter [10.24.76.104] LSI MegaRAID SAS 9280-8e (3): BBU temperature problem detected

(7) [PRIMEQUEST 1000 Series]

The Unit name of the ServerView event message is displayed with Seg:Bus:Dev.Func (example 0:0:25.0).

- Unit name in Partition Event Log on MMB screen.
- Unit name in output event of ServerView.

Refer to “9 Procedure for specifying PCI card error part in VMware5” of “PRIMEQUEST 1000 Series ServerView Mission Critical Option User Manual” for details.

(8) [PRIMEQUEST 1000 Series]

When the environment is configured of Windows Server 2012, use since SVmcovm 1.2.0.0.

(9) [PRIMEQUEST 1000 Series]

When the environment is configured of VMware ESXi5.5, the message that fails in the System Status Change might be output to Syslog or Eventlog.
However, the operation (restart of SVmcovm) described in the manual is unnecessary.

The message is the following.
Event ID: 09135
The message: System Status is Changed in the “OS Running”: failed ret=%1
%1 is arbitrary numerical value.

6. Notes on ServerView ESXi CIM Provider

(1) [PRIMEQUEST 2000/1000 Series]

For monitoring PRIMEQUEST 1000 series, Use ServerView CIM Provider V6.0 or later version.

7. Notes on ServerView Installation Manager (SVIM)

(1) [PRIMEQUEST 2000 Series]

You cannot use the SVIM V11.14.02 for OS installation of PRIMEQUEST 1000 series.

Please use the "manual installation guide".

(2) [PRIMEQUEST 1000 Series]

A warning message may appear when HBAnyware starts.

If ServerView Installation Manager automatically installs the application HBAnyware, the following warning message may appear when HBAnyware starts. You can ignore this message.

"RMServer: Failed to register remote request handler for adapter 0 with

(3) [PRIMEQUEST 1000 Series]

Note the following points about configuring the RAID and disks in Guide mode.

Do not configure a disk partition across multiple disks. To configure a disk partition across multiple disks, do so manually after the installation is completed.

(4) [PRIMEQUEST 1000 Series]

To connect eight or more PCI cards, the I/O space assignment must be changed. Note the following.

- Assign I/O space to the SASU/SASRU.
- For installation in a SAN environment, assign I/O space to the FC card that connects the SAN environment.
- For remote installation, assign I/O space to the built-in LAN port.

For details on I/O space assignment, see 5.5 [Device Manager] Menu in the *PRIMEQUEST 1000 Series Tool Reference* (C122-E110EN).

(5) [PRIMEQUEST 1000 Series]

Note the following about using the Dual Chanel SAS array controller card.

Before using the Dual Channel SAS array controller card (RAID card for an external disk unit) in Red Hat Enterprise Linux, assign I/O space.

After Red Hat Enterprise Linux is installed, if no I/O space is assigned when that card is installed, the operating system may not start.

For details on I/O space assignment, see 5.5 [Device Manager] Menu in the *PRIMEQUEST 1000 Series Tool Reference* (C122-E110EN).

(6) [PRIMEQUEST 1000 Series]

Note the following about a SAN or other environment that is connected to many hard disks and LUNs.

This software can recognize up to 64 hard disks or LUNs.If many hard disks or LUNs are connected, it may not recognize the installation destination.If possible, remove all the hard disks or LUNs that are not the installation destination.

(7) [PRIMEQUEST 1000 Series]

Note the following about installing an operating system that does not support UEFI.

The PRIMEQUEST is in UEFI mode when shipped from the factory.Before installing an operating system that does not support UEFI, set BIOS mode.

The operating systems that support UEFI are as follows:

Windows Server 2008 (64 bit)
Windows Server 2008 R2
Red Hat Enterprise Linux 6 (for Intel64)

To set BIOS mode, use the following procedure.

1) After powering on the partition, press the [F2] key while the FUJITSU logo is displayed to open the UEFI window.

2) Select the following menu items in the UEFI window, in the order shown:
[Boot Maintenance Manager]－[Boot Options]－[Change Boot Order]－[Change the order]

3) Specify that [**Legacy Boot**] be at the top.

The following shows the meanings of the menu items.

UEFI: Embedded DVD/CD	Specify this item to use the built-in DVD drive for installation in UEFI mode.
Legacy Boot	Specify this item to set BIOS mode.Specify it also to use remote storage for installation in BIOS mode.
UEFI Shell	Use it to display the UEFI command prompt at startup.

4) Specify [Commit Changes and Exit] - [Reset System], and reboot the partition.

(8) [PRIMEQUEST 1000 Series]

When you install the Red hat Enterprise Linux5 with Xen kernel, please operate according to the following procedure.

・Installation Manager Deployment Process Selection Screen

1) Select deployment process as “Customised” .

・Package Selection Screen

2) Input installation number.
3) Check the item of “native Kernel”.
4) Check the check box of “Virtual environment” in Select packages.

・Grub　Bootloader Option /Mount Options Screen

5) Check the check box of “Install Bootloader”.
6) Check the check box of “Boot XEN kernel as default”.

(9) [PRIMEQUEST 1000 Series]

You cannot use guided mode in remote installation.

(10)[PRIMEQUEST 1000 Series]

Note the following about using many CPU/PCI card.

When many CPU/PCI card mounted, after choosing OS, a warning message may be displayed on OS selection Screen. Please install by once constituting small then.

(11)[PRIMEQUEST 1000 Series]

When 16 or more LAN cards are mounted, a screen may freeze in Language Selection.

If you wait for a while after a screen freezes, it will recover, but if you reduce the number of LAN cards, a symptom can be canceled.

(12)[PRIMEQUEST 1000 Series]

Please register the boot manager, when you install the VMware ESXi 5.x in UEFI mode.

Procedure is the following.

1) After power on, push F2 key while FUJITSU logo is displayed. The following UEFI screen is displayed.

2) Select the menu in order to the below.

[Boot Maintenance Manager]-[Boot Options]-[Delete Boot Option]

3) Position cursor in VMware ESXi 5.x, and push the space bar on it.



4) Select [Commit Change and Exit].
5) Select [Add Boot Option].
6) Select the item of top “ESXi …..”



7) Select <EFI>^<BOOT>^Bootx64.EFI.
8) Input the following strings into the item of [Input the description] as the item of boot manager.
“VMware ESXi 5.x”



9) Select [Commit Changes and Exit].



Setup is over. After that, push Enter key and reboot the server.

(13)[PRIMEQUEST 1000 Series]

If you have two or more disks, please install VMware ESXi to first one.

(14)[PRIMEQUEST 1000 Series]

VMware ESXi cannot perform remote installation in UEFI mode.

(15)[PRIMEQUEST 1000 Series]

If you install OS with UEFI mode, you have to remove the JX40.

(16)[PRIMEQUEST 1000 Series]

If you install VMware ESXi 5.5 with UEFI mode, please take care of the following attention.

After automatic installation starts, there is an inquiry for parameter of configuration. Please input parameter again as the same as you input in GUI screen.

8. Notes on ServerView Update Manager (SVUM)

(1) [PRIMEQUEST 2000/1000 Series]

PRIMEQUEST does not support this product.

9. Notes on ServerView Update Manager Express (SVUME)

(1) [PRIMEQUEST 2000/1000 Series]

PRIMEQUEST does not support this product.

EOF